



VistaView CableTec[®] Installation Guide for 1/8" Assembly Kits

Important Tips:

- *Space cables no more than 3 - 1/2" apart and have a post or vertical picket at least every 4 feet to minimize cable deflection.
- *Straight runs should not exceed 60 feet, 1-corner runs 45 feet and 2 -corner runs 30 feet.
- *For wood posts, use protector sleeves wherever the cable enters/exits a post on an angle.

*For angled terminations (stairs), use angled washers.

Drill Hole Sizes:

Threaded Terminal = 5/16"

Intermediate Posts = 3/16"

SwiftCatch = 3/8"

Step -By -Step Installation Instructions:

- 1 Mark drill hole locations on posts and drill holes. Hole diameters depend on cable size and fitting.
- 2 Insert the threaded terminal end of the assembly through the end post and attach a washer -nut. Spin the nut so that 1/4" of the thread is exposed.
- 3 Thread the bare end of the cable through the intermediate posts and through the opposite end post. Slide on a flat washer and SwiftCatch until they rest against the face of the post.
- 4 Hold the SwiftCatch fitting with one hand and pull the cable tight with the other. The fitting will automatically lock onto the cable when you release it.
- 5 Tighten the washer -nuts on the threaded terminal to properly tension the run. As you tighten the washer -nut, hold the cable on the inside of the post with vise grip pliers to prevent the cable from spinning. Tighten until you cannot flex the cables more than 4 inches apart.
- 6 Saw or grind off the excess threads of the terminal as close to the washer -nut as possible.
- 7 Use cable cutters or a cutoff disc to trim the excess cable outside the SwiftCatch.
- 8 Snap on end caps over the exposed washer -nut and SwiftCatch ends.
- 9 Repeat for remaining cables until your project is complete.
- 10 *Enjoy the view!*